

## **MARMOX WATERPROOF CORNER PIECES**

# Internal Corners



### **Application area**

For the safe and secure sealing of the wall to a Marmox showerlay in the corner.

### **Method of use**

- Can be used in combination with Marmox self-adhesive waterproof tape.
  - Waterproof Corners are NOT self-adhesive and should be fixed using a cement based (powder) tile adhesive.
  - Fix the Waterproof Corners BEFORE fixing the Waterproof Tape.
1. Paste a thin but even layer of cement-based tile adhesive onto the back of the corner piece and place into position.
  2. Press it into position with a trowel so that adhesive is just squeezed out at the edges. *You must be confident that the entire surface is coated is bonded with no gaps.*
  3. Scrape away any excess tile adhesive that has been squeezed out.
  4. Marmox Self-Adhesive Waterproof Tape should be used to waterproof the neighboring gaps and joints when the tile adhesive has dried. This tape should overlap the Waterproof Corners by at least 5 cm.

### **Technical Properties**

<b>Description</b>	Stable joint sealing tape, with good stability lengthwise and excellent elasticity crosswise, made of polyester fleece coated with TPE (Thermoplastic elastomer).
<b>Colour</b>	grey
<b>Total width</b>	120 mm
<b>Width of coating</b>	120 mm
<b>Total thickness</b>	approx. 0.67 mm
<b>Max. tensile strength length.</b>	approx. 122 N/15mm
<b>Max. tensile strength cross.</b>	approx. 34.8 N/15mm
<b>Elongation at break length.</b>	approx. 29 %
<b>Elongation at break cross.</b>	approx. 170 %
<b>UV resistant:</b>	yes
<b>Processing temperatures:</b>	-30 °C/+90 °C