



1 Decide where you want the Showerlay to be placed and sit the 2 parts of the Showerlay Plinth into place. Be aware of floor level at all stages.



2 Sit the Showerlay on top of the Plinth making sure the Showerlay is not over hanging the Plinth on any sides.



3 Mark out the position of the hole and also draw around the edges of the Showerlay with a pencil onto the Plinth.



4 Remove the Showerlay and place the Dallmer drain upside down over the circle drawn on the Plinth. Now draw a pencil line around the Dallmer drain leaving roughly a 10mm gap.



5 Cut both parts of the Plinth to size by cutting along the pencil lines.



6 Cut out the hole for the drain and also space for the pipework.



7 Lay the Plinth into position then mark the wall for the pipework. Now once again remove the Plinth and drill out the hole drawn on the wall.



8 Now fix down the Plinth to the floor using a full bed of flexible cement based tile adhesive. Use the adhesive to help level any uneven floors.



9 Connect the Dallmer drain to the pipe, feed through the wall. Allow the drain enough space to move freely up and down. Check that the black rubber ring is on top of the drain.



10 Now fix down the Showerlay to the Plinth once again using a full bed of flexible cement based tile adhesive.



11 It is critical to make sure the Showerlay is level on all edges to ensure that when being used, all water will drain away.



12 Screw the white plastic ring through the Showerlay into the Dallmer drain below. To do this, reach your thumb through the hole and lift the drain up to the thread.



13 Using the tool provided to screw the plastic ring as tight as possible.



14 Place the hair trap inside.



15 Push in the white funnel.



16 You can also apply Marmox Multiboards to the surrounding walls and floor. Now it is ready to tile and to add the desired show enclosure.